

TKG-104-TOUCH-IP68-VESA-GREY





PRODUCT FEATURES

- Integrated touchpad •
- VESA-M5-boreholes (distance 75 x 75 mm) •
- IP68 sealing, can be submerged into liquids •

SPECIFICATION

Number of keys: Housing type: Material keypad / bottom: Colour: Keyswitch technology: Operating force: Switch travel: Switching cycles: Protection level: Interface: USB compatibility: Operating temperature: Storage temperature: Dimensions: Weight: Certification: Warranty:

104 desktop housing silicone / plastic grey, black carbon contacts 1.5 N (numpad 1.1 N) 1.4 mm 2 mill. (per key) IP68 USB USB V1.1/2.0 compliance 0 °C to +60 °C -20 °C to +70 °C 340 x 165 x 16.3 mm 735 g CE, RohS, REACH, EMC, FCC 4 years on the electrical function

- Special coating for excellent mechanical and chemical resistance .
- Can be cleaned and desinfected thoroughly .
- Robust, durable silicone material .

TOUCHPAD SPECIFICATION

Operating principle:	capacitive
Resolution:	1400 dpi
Dimensions:	65 x 49 mm
USB compatibility:	compliant with USB 2.0

VESA INSERT NUTS SPECIFICATION

Thread:	M5
Material:	1.5 mm steel
Recommended screw	
tightening torque:	3.60 Nm
Resistance to distortion:	8.47 Nm
Axial force:	3110 N

Cat.No.	Product description	Colour	Layout
KG17201	TKG-104-TOUCH-IP68-VESA-GREY-USB-DE	Grey	German
KG17202	TKG-104-TOUCH-IP68-VESA-GREY-USB-US	Grey	US
KG18216	TKG-104-TOUCH-IP68-VESA-BLACK-USB-DE	Black	German
KG19221	TKG-104-TOUCH-IP68-VESA-BLACK-USB-US	Black	US
TRATOLET	TKG-104-TOUCH-IP68-VESA-BLACK-USB-US	Black	US

hnology

Rev. 0-06 2019



TEL 02 9457 6400 sales@backplane.com.au www.backplane.com.au

Subject to modifications and errors



Additional functions of the touch pad

Your device has a new touch pad and it provides the following additional functions:

- 1. You can adjust the sensitivity level
- 2. You can reproduce the mouse buttons
- 3. You can reproduce the scroll wheel
- 4. You can reproduce holding down the left mouse button and moving it [tap and hold]

1. Adjusting the sensitivity level



You can adjust the sensitivity level of the touch pad.

When delivered, the sensitivity is set at the lowest level.

You can adjust the sensitivity of the touch pad as follows:

• Press and hold both mouse buttons for approx. 5 sec. \rightarrow the cursor starts to rotate.

• You can adjust the sensitivity level by moving your fingers across the touch pad horizontally; the level is indicated by the rotation circle of the cursor:

- Small circle lower sensitivity
- Large circle higher sensitivity
- The cursor stops rotating 5 seconds after you release the mouse buttons and the touch pad is then ready for use.



Additional functions

Systems

3. Scroll wheel	Stroke the touch pad with two fingers in a vertical direction
4. Hold down the left mouse button and move [tap and hold]	Tap the touch pad and keep your finger on the touch pad for a short time



Backplane Systems Technology Pty Ltd

TEL 02 9457 6400 sales@backplane.com.au www.backplane.com.au alian-owned Since 1989 Subject to modifications and errors



TECHNICAL DRAWING (in mm)







Subject to modifications and errors



TECHNICAL DRAWING (in mm)



SPECIFICATION

- Rear side integrated VESA screwing holes (distance 75 x 75 mm) can be opened neatly and burr-free by using a 5.2 mm drill; Plastic shavings can be removed with tweezers.
- The key lock allows for a cleaning even while the system - is running (push the button 3 sec.)





Backplane Systems Technology Pty Ltd

TEL 02 9457 6400 sales@backplane.com.au www.backplane.com.au

Proudly Australian-Owned Since 1989